

Recommendations for Inflatable Dinghies



Put both “V-Fittings” on the Forward Tongue Tube.



Adjust Axle Location on Aft Tongue Tube based on boat length and other load variables like the engine. Move it farther back for a heavier engine and farther forward for a light engine or no engine. The goal is to achieve a handle weight of 20lbs or less. Small changes can make a big difference!

